

Cabinet Care



- Use a soft cotton cloth.
 - Do not use abrasive materials (including paper towels).
 - Only use soap and warm water.
 - Do not spray directly onto the cabinets.
 - Do not use any chemicals.
- (Note, when using a spray for other items placed near your cabinetry, be careful not to overspray on your cabinets)
- Wipe spills promptly and do not leave wet items against the wood.
 - Clean glass doors with a glass cleaner.
 - Be careful not to overspray on the wood.
 - You can repair small nicks and scratches with our touch up kits.
 - Waxing and polishing are not recommended as this can create a film or wax build-up on your cabinets.
 - You can dust your cabinets with a lightly damp cloth.
 - Follow the grain of the wood. Wiping across can cause scratches.

Glide-Lock Mfg, Inc
3916 N Potsdam Ave Suite 231
Sioux Falls, SD 57104
sales@glidelock.com